



**Nelson & Nelson Mfg.**  
5210 Stadium Blvd. Suite C  
Jonesboro AR 72404  
870-268-6393 : Cell 219-1019

Installation Instructions 2-22-23

### **Model SF3-PRCK**

***For all F3s & F3-T Models with BRP Passenger Backrest***

## **Steps needed to install your F3 Rear Rack** **DO NOT USE IMPACT DRILL ON BOLTS OR NUTS.**



### **Complete Kit shown above.**

1.- First remove the 4 bolts from the rear of the F3 Passenger backrest. When installing the new bolts use **Loctite Blue Thread Locker on all bolts**. Then take the FOUR spacers and place between rack and backrest mount. Take the new bolts, the shorter of the 4 bolts and place the rack as shown below placing the small bolts through the bolt cover washer. Do this for the two top bolts. Then take the longer spacers and bolts and place them through the bolt cover washer and secure them in the two lower holes. Do not tighten down until all bolts are installed. Once installed tighten down all bolts. Then place the plastic cover over each bolt.

**Your New Passenger Backrest Rack is now installed!**

We thank you for purchasing one of our F3 Accessory Kits. Today we know the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder!

**Spyderextras.com**